


Troubleshooting Tips for Electric Motors


Repeated use or rough handling of the electric motor with wire leads and alligator clips may cause the wire leads to become detached from the posts of the electric motor. If this should happen, you can still continue to use the electric motor by substituting one of the insulated connector wires with an alligator clip on each end (provided in the unit) for the damaged wire lead on the motor.

Try the following troubleshooting approaches for the electric motors included with the STC/MS[®] *Energy, Machines, and Motion Unit Kit*:

- Make sure the alligator clip connects directly to the post of the electric motor.



- Then connect the alligator clip from the opposite end of the same insulated connector wire to a battery or another wire lead.



CAROLINA

Carolina Biological Supply Company

800.334.5551

www.carolina.com